

FOR OFFICIAL USE ONLY



U.S. AIR FORCE SKL (Simple Key Loader) Instruction Guide




Table of Contents

Page 1 – Initializing SKL

Page 2 – Deleting Superseded Codes

Page 3 – Loading Secure Voice

Page 4 – Loading Precision Codes (GPS)

Page 5 – Loading Mode 4 (IFF)

Page 6 – Loading Combat Track II (CT2)

Page 7 – Transfer of Segments from SKL → SKL

Page 8 – Powering Down SKL

If you follow the step-by-step instruction in this guide, you WILL be able to load all codes!

DO NOT:

- **Push any buttons** beside the Dim/Bright Buttons **while unit is Powering On...**
(until Log In Screen Appears)
- **Remove CLK unless operational necessity dictates** → for instance, if the unit will become compromised (codes may dump)
- **Remove battery while SKL is powered ON**
(codes will dump)

Initializing SKL

Step 1 – Push the **GREY** power button on top right until screen comes up (roughly 3 seconds)

Step 2 – Wait for Logon Screen to appear

→ If screen is too dark or bright, use the bottom left & right push buttons to adjust
(LEFT Button = DARKER RIGHT Button = BRIGHTER)

→ If Logon Screen does NOT automatically appear, TAP the **CoreLib** Icon

<USER ID AND PASSWORD ARE CASE SENSITIVE!>

Step 3 – Enter User ID

Step 4 – Enter Password

Step 5 – Press “OK”

Depending on how SKL is configured, Steps 6 & 7 may automatically be bypassed directly to Step 8

Step 6 – Select “Launch” → “Launch UAS” from top menu bar

Step 7 – Highlight “SKL” (if not highlighted already) in Launch UAS dialog box and press “OK”

Step 8 – Press “OK” when Startup Information dialog box appears

Step 9 – Codes that are loaded on the SKL should appear....
If not, click on the Keys Tab

Deleting Superseded Codes

Continue from Keys Tab (Page 1, Step 9):

Step 1 – On the top Menu, select View→Keys→Expired Keys

Step 2 – Record keys and segment numbers that will be deleted on the Electronic Key Management Log

You will need to scroll to the right to see the segment number

Step 3 – In the Expired Keys Dialog Box, Select “Delete All”

Step 4 – Select “Yes” when asked whether to “*Delete All Segments?*”

Step 5 – Select “OK” on deletion confirmation dialog box

Step 6 – Select “Close” at bottom right of the Expired Keys Dialog Box

Step 7 – To ensure all expired keys were deleted, repeat Step 1.

You should receive confirmation that “*No Expired Keys Exist*”

When Logging out or powering off the unit, a dialog box asks you:

“The database has changed. Do you want to save the changes?”

Always Always Always Select “YES”!

If you select “**NO**”, the codes you thought you deleted will still be there.

Loading Secure Voice

Continue from Keys Tab (Page 1, Step 9):

Step 1 – Expand **AKAD 1604** by selecting the + icon.

Continue expanding items until the Key Icons are in view

Step 2 – Highlight the Key which you wish to load

Step 3 – Select “*Load Icon*” on the top right of the Screen

Step 4 – Using drop down menu, change Protocol to DS-102
(DS-102 should be the default)

Step 5 – Using drop down menu, change Activate Mode to **KYK-13**

Step 6 – Select “OK” at the bottom of the dialog box

Step 7 – **Connect SKL Fill Cable** to Secure Voice Receptacle

Step 8 – Ready to Send Key Dialog Box should appear, Select “OK”

Step 9 – When the screen tells you to **INITIATE**, initiate on the Secure Voice Radio.

Codes loaded correctly → dialog box w/ “*Operation Successful*” will appear

Step 10 – Return to Step 1 and repeat for all Secure Voice Radios

Step 11 – **Disconnect Fill Cable**

Loading Precision Codes (GPS)

Continue from Keys Tab (Page 1, Step 9):

Step 1 – Expand AKAD A1105 by selecting the + icon.

Continue expanding items until the Key Icons are in view

Step 2 – Highlight the Key which you wish to load

Step 3 – Select “*Load Icon*” on the top right of the Screen

Step 4 – Using drop down menu, change Protocol to DS-102
(DS-102 should be the default)

Step 5 – Using drop down menu, change Activate Mode to KYK-13

Step 6 – Select “OK” at the bottom of the dialog box

Step 7 – **Connect SKL Fill Cable** to GPS Precision Code Receptacle

Step 8 – Ready to Send Key Dialog Box should appear, Select “OK”

Step 9 – When the screen tells you to **INITIATE**, initiate on the GPS Precision Code Panel.

Codes loaded correctly → dialog box w/ “*Operation Successful*” will appear

Step 10 - In SCNS, Select NAV → INIT → GPS INIT → Page 2-2 to ensure that P-Codes loaded

P-Codes loaded – Not Verified or Verified on Page 2-2 in SCNS

P-Codes did not load – Not Loaded on Page 2-2 in SCNS

Step 11 – **Disconnect Fill Cable**

Loading Combat Track II (CT2)

Continue from Keys Tab (Page 1, Step 9):

- Step 1** – Expand USKAD C5918 by selecting the + icon.
Continue expanding items until a Key Icon is in view
- Step 2** – Highlight the Key you wish to load, (**Confirm key to be loaded**)
- Step 3** – Select “Load Icon” on the top right of the Screen
- Step 4** – Using drop down menu, change Protocol to DS-102
- Step 5** – Using drop down menu, change Activate Mode to KYK-13
- Step 6** – Ensure Thornton Key / ADDI Key Load Drop Down Box is UNCHECKED
- Step 7** – Select “OK” at the bottom of the dialog box
- Step 8** – **Connect SKL Fill Cable** to CT2 Transceiver FILL Receptacle J6
- Step 9** – “*Press INITIATE Button*” Dialog Box should appear,
- Step 10** -- Press CT2 Transceiver “ENTER” button to INITIATE crypto key load...immediate flash of green confirm light then distinguishes → dialog box w/ “*Operation Successful*” will appear
- Step 11** -- Look for Transceiver Lite illumination:
GREEN CONFIRM lite – **ON**, **RED CRYPTO FAULT** Lite – **OFF**
→ Good Load of Key Codes on the CT2 Transceiver when cable is disconnected or wait ten sec after keying while cable is still attached
GREEN CONFIRM lite – **OFF**, **RED CRYPTO FAULT** Lite – **ON**
→ Codes NOT loaded correctly due to either:
= FILL Cable NOT properly seated on SKL or Transceiver
= SKL CT2 Steps 4-5 are not configured properly
= Key is corrupt
- Step 12** – **Disconnect Fill Cable**

Loading Mode 4 (IFF)

Continue from Keys Tab (Page 1, Step 9):

Step 1 – Expand AKAD A3662 by selecting the + icon.

Continue expanding items until a Key Icon is in view

Step 2 – Highlight the Key you wish to load

You must load the corresponding daily “A” code prior to repeating all steps for the corresponding daily “B” code

Step 3 – Select “Load Icon” on the top right of the Screen

Step 4 – Using drop down menu, change Protocol to DS-102

Step 5 – Using drop down menu, change Activate Mode to IFF

Step 6 – Select “OK” at the bottom of the dialog box

Step 7 – **Connect SKL Fill Cable** to IFF Mode 4 Receptacle

Step 8 – “Ready to Send Key” Dialog Box should appear, Select “OK”

Step 9 – Repeat all steps to load daily “B” code

GREEN light flash on the IFF Mode 4 Receptacle after loading the daily “B” code (If not, the codes were not loaded correctly)

Step 10 – **Disconnect Fill Cable**

Transfer of Segments **from SKL → SKL**

Continue from Keys Tab (Page 1, Step 9):

Transmitting SKL:

- Step 1** – Select “File”
- Step 2** – Select “Transmit”
- Step 3** – Select “Database”
- Step 4** – Click “NEXT”
- Step 5** – Select “SKL”
- Step 6** – Click “NEXT”
- Step 7** – **Connect Fill Cable to SKL**
- Step 8** – Select “TRANSMIT”
- Step 9** – **Disconnect Fill Cable**

Receiving SKL:

- Step 1** – Select “File”
- Step 2** – Select “Receive”
- Step 3** – Select “Database”
- Step 4** – Change Source to “SKL”
- Step 5** – Connect Fill Cable to SKL
- Step 6** – Click “RECEIVE” once
STEP 8 is completed on
TRANSMITTING SKL
- Step 7** – **Disconnect Fill Cable**

Powering Down SKL

Continue from Keys Tab (Page 1, Step 9):

Step 1 – Select “X” in the top right corner to close window

Step 2 – Select “YES” to save changes. This will take you to the CoreLib page (AVENGER HUMMV picture)

When Logging out or powering off the unit, a dialog box may ask you:

“The database has changed. Do you want to save the changes?”

Always Always Always Select YES!

If you select **NO**, the codes that you thought you deleted will still be there.

If dialog box does not appear, go to:

FILE → SAVE DATABASE

Step 3 – Select “X” in top right corner to close out CoreLib application

Step 4 – Push Grey power button on top right until “Shutdown” pop-up box appears (roughly 1 second)

→ Countdown to power-off screen will appear

Step 5 – Ensure that extremely expensive & hip stylus are stowed prior to stowing SKL